



CAUTION
TURN OFF POWER
BEFORE REMOVING
TUBES

VOLTAGE & RESISTANCE READINGS
FUNCTION SWITCH IN AUX POSITION
STEREO SWITCH IN MON. POSITION
LOUDNESS CONTROL MIN. CCW
CONTOUR SW. OUT, LOW & HIGH CUT OUT
TAPE MONITOR OUT
BLEND CONTROL IN STEREO
BASS & TREBLE CONTROLS FLAT
BALANCE CONTROL CENTERED

ITEM	TUBE	PN 1	PN 2	PN 3	PN 4	PN 5	PN 6	PN 7	PN 8	PN 9
V1	12AX7	1.380K	1M	2.2K	—	—	1.600K	84K	2.2K	—
V2	12AX7	1.380K	1M	2.2K	—	—	1.600K	84K	2.2K	—
V3	12AX7	1.180K	1M	1.8K	—	—	1.180K	1M	1.8K	—
V4	7199	1.17K	1.820K	1.680K	—	—	1K	1M	12K	1.220K
V5	7199	1.17K	1.820K	1.680K	—	—	1K	1M	12K	1.220K
V6	7591	—	—	140	220	—	120K	—	220	—
V7	7591	—	—	140	220	—	120K	—	220	—
V8	7591	—	—	140	220	—	120K	—	220	—
V9	7591	—	—	140	220	—	120K	—	220	—

* RESISTANCE READINGS MARKED WITH ASTERISK ARE MEASURED FROM THE JUNCTION OF R81 & C53.

- NOTES
- 1- UNLESS OTHERWISE SPECIFIED
 - 2- ALL RESISTANCE VALUES IN OHMS ±10%
 - 3- ALL RESISTORS 1/2 WATT.
 - 4- ALL CAPACITORS WITH DECIMAL VALUES IN UF.
 - 5- ALL CAPACITORS WITHOUT DECIMAL VALUES IN UUF.
 - 6- ALL VOLTAGES ARE DC & MAY VARY ±20%.

A700